User Manual

Mobile Phone

Model：X624B

Hereby, INFINIX MOBILITY LIMITED declares that this Mobile Phone is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/ EU.

Know your phone



1. Front camera
2. Flash
3. Volume + key
4. Volume - key
5. Power key

SIM/SD card installation

1. Power off mobile.

2. Refer to the following picture for SIM / SD card installation.



Charging the phone

You can charge your device using a charger or by connecting it to the computer using a USB cable (comes with the phone).

1. Please remind the front and back of the plug.
2. Use only INFINIX charger and cables. Other chargers or cables may damage the device. This will invalidate your phone warranty.

Connaître votre téléphone



1. Appareil photo frontal
2. Flash
3. Touche de volume +
4. Touche de volume –
5. Bouton d’alimentation

Installation de la carte SIM/SD

1. Éteindre le téléphone

2. Reportez-vous à l'image suivante pour l'installation de la carte SIM/SD.



Charger le téléphone

Vous pouvez charger votre appareil à l'aide d'un chargeur ou en le connectant à l'ordinateur à l'aide d'un câble USB (fourni avec le téléphone).

1. Ne mélangez pas l'avant et l'arrière de la fiche.

2. Utilisez uniquement le chargeur et les câbles INFINIX. D'autres chargeurs ou câbles peuvent endommager l'appareil. Cela annulera la garantie de votre téléphone.

شحن الهاتف

يمكنك شحن جهازك باستخدام شاحن أو عن طريق توصيله بجهاز الكمبيوتر باستخدام كبل USB (يتوفر مع الهاتف).

1. يُرجى التمييز بين وجه القابس وظهره.
2. استخدم فقط كابلات أو شاحن INFINIX. قد تتسبب الشواحن أو الكابلات المختلفة في تلف الجهاز. وهذا من شأنه أن يُبطل ضمان هاتفك.

تثبيت بطاقة SIM وبطاقة الذاكرة

1.قم بإيقاف تشغيل الهاتف

2. أدخل بطاقة SIM وبطاقة الذاكرة كما هو مبين في الصورة.



اكتشف هاتفك

1. الكاميرا الأمامية
2. الفلاش
3. مفتاح زيادة مستوى الصوت
4. مفتاح خفض مستوى الصوت
5. مفتاح التشغيل والإيقاف

Operating Frequency Band (RF)：

E-GSM900: 880-915MHz (TX), 925-960MHz (RX)
DCS1800: 1710-1785 MHz (TX), 1805-1880 MHz (RX)
WCDMA BAND I:1920-1980 MHz (TX), 2110-2170 MHz (RX)
Bluetooth: 2400-2483.5 MHz (TX/RX)
WiFi: 2412-2472 MHz (TX/RX)
GPS:1.57542GHz
FM:87.5 MHz -108 MHz

Modulation mode：

GMSK, 8PSK (GSM)
GMSK,8PSK(GSM)
BPSK,QPSK,16QAM(WCDMA)
GFSK, π/4- DQPSK, 8DPSK (BT)
GFSK(BLE)
BPSK/QPSK/16QAM/64QAM/DSSS/OFDM/ CCK (WIFI b/g/n)
BPSK(GPS)

RF output power：

GSM900：33dBm±2dB

GSM1800：30dBm±2dB

WCDMA BAND I:24dBm+1.7dB/-3.7dB

Bluetooth：0-10dBm

Wifi: 14dBm+/-3dB

Specific Absorption Rate (SAR) Certification

THIS DEVICE MEETS INTERNATIONAL GUIDELINES FOR EXPOSURE TO RADIO WAVES

Body parts	Test value	Test distance	Limit
Head	0.449 W/Kg 10g	0cm	2.0 W/Kg 10g
Body	0.298 W/Kg 10g	0.5cm	2.0 W/Kg 10g

CAUTION :

1. Use careful with the earphone maybe excessive sound pressure from earphones and headphones can cause hearing loss.
2. Risk of explosion if battery is replaced by an incorrect type, dispose of used batteries according to the instructions.
3. The product shall only be connected to a USB interface of version USB 2.0.
4. Adapter shall be installed near the equipment and shall be easily accessible.
5. EUT Temperature: -10℃° ~ +65℃°.
6. Adapter 1: U060XKA
   Input: 100-240V~50/60Hz 300mA
   Output: DC 5.0V 1.2A
   Adapter 2: U060XEA
   Input: 100-240V~50/60Hz 200mA
   Output: DC 5.0V 1.2A
7. The device complies with RF specifications when the device used at 5mm from your body.
8. To prevent possible hearing damage, do not listen at high volume levels for long periods.
9. Earphone and USB cable are shielded.

Figure 1 - Warming label (IEC 60417-6044)

User Manual

Mobile Phone

Model：X624B

Hereby, INFINIX MOBILITY LIMITED declares that this Mobile Phone is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/ EU.

Know your phone



1. Front camera
2. Flash
3. Volume + key
4. Volume - key
5. Power key

SIM/SD card installation

1. Power off mobile.

2. Refer to the following picture for SIM / SD card installation.



Charging the phone

You can charge your device using a charger or by connecting it to the computer using a USB cable (comes with the phone).

1. Please remind the front and back of the plug.
2. Use only INFINIX charger and cables. Other chargers or cables may damage the device. This will invalidate your phone warranty.

Connaître votre téléphone



1. Appareil photo frontal
2. Flash
3. Touche de volume +
4. Touche de volume –
5. Bouton d’alimentation

Installation de la carte SIM/SD

1. Éteindre le téléphone

2. Reportez-vous à l'image suivante pour l'installation de la carte SIM/SD.



Charger le téléphone

Vous pouvez charger votre appareil à l'aide d'un chargeur ou en le connectant à l'ordinateur à l'aide d'un câble USB (fourni avec le téléphone).

1. Ne mélangez pas l'avant et l'arrière de la fiche.

2. Utilisez uniquement le chargeur et les câbles INFINIX. D'autres chargeurs ou câbles peuvent endommager l'appareil. Cela annulera la garantie de votre téléphone.

شحن الهاتف

يمكنك شحن جهازك باستخدام شاحن أو عن طريق توصيله بجهاز الكمبيوتر باستخدام كبل USB (يتوفر مع الهاتف).

1. يُرجى التمييز بين وجه القابس وظهره.
2. استخدم فقط كابلات أو شاحن INFINIX. قد تتسبب الشواحن أو الكابلات المختلفة في تلف الجهاز. وهذا من شأنه أن يُبطل ضمان هاتفك.

تثبيت بطاقة SIM وبطاقة الذاكرة

1.قم بإيقاف تشغيل الهاتف

2. أدخل بطاقة SIM وبطاقة الذاكرة كما هو مبين في الصورة.



اكتشف هاتفك

1. الكاميرا الأمامية
2. الفلاش
3. مفتاح زيادة مستوى الصوت
4. مفتاح خفض مستوى الصوت
5. مفتاح التشغيل والإيقاف

Operating Frequency Band (RF)：

E-GSM900: 880-915MHz (TX), 925-960MHz (RX)
DCS1800: 1710-1785 MHz (TX), 1805-1880 MHz (RX)
WCDMA BAND I:1920-1980 MHz (TX), 2110-2170 MHz (RX)
Bluetooth: 2400-2483.5 MHz (TX/RX)
WiFi: 2412-2472 MHz (TX/RX)
GPS:1.57542GHz
FM:87.5 MHz -108 MHz

Modulation mode：

GMSK, 8PSK (GSM)
GMSK,8PSK(GSM)
BPSK,QPSK,16QAM(WCDMA)
GFSK, π/4- DQPSK, 8DPSK (BT)
GFSK(BLE)
BPSK/QPSK/16QAM/64QAM/DSSS/OFDM/ CCK (WIFI b/g/n)
BPSK(GPS)

RF output power：

GSM900：33dBm±2dB

GSM1800：30dBm±2dB

WCDMA BAND I:24dBm+1.7dB/-3.7dB

Bluetooth：0-10dBm

Wifi: 14dBm+/-3dB

Specific Absorption Rate (SAR) Certification

THIS DEVICE MEETS INTERNATIONAL GUIDELINES FOR EXPOSURE TO RADIO WAVES

Body parts	Test value	Test distance	Limit
Head	0.449 W/Kg 10g	0cm	2.0 W/Kg 10g
Body	0.298 W/Kg 10g	0.5cm	2.0 W/Kg 10g

CAUTION :

1. Use careful with the earphone maybe excessive sound pressure from earphones and headphones can cause hearing loss.
2. Risk of explosion if battery is replaced by an incorrect type, dispose of used batteries according to the instructions.
3. The product shall only be connected to a USB interface of version USB 2.0.
4. Adapter shall be installed near the equipment and shall be easily accessible.
5. EUT Temperature: -10℃° ~ +65℃°.
6. Adapter 1: U060XKA
   Input: 100-240V~50/60Hz 300mA
   Output: DC 5.0V 1.2A
   Adapter 2: U060XEA
   Input: 100-240V~50/60Hz 200mA
   Output: DC 5.0V 1.2A
7. The device complies with RF specifications when the device used at 5mm from your body.
8. To prevent possible hearing damage, do not listen at high volume levels for long periods.
9. Earphone and USB cable are shielded.

Figure 1 - Warming label (IEC 60417-6044)